

Technical Support support@nuvationenergy.com Sales Inquiries sales@nuvationenergy.com 855-261-0507

# Nuvation Energy Battery Stack Emulator Product Manual

Document ID: NE-PM-014 | Revision: 1.1, 2024-07-16

BSE Software Version: 1.0.0 © 2024 Nuvation Energy

# Table of Contents

1.	Introduction			 	. 1
	1.1. About this Manual			 	. 1
2.	Product Overview			 	. 2
3.	Installation Instructions			 	. 3
	3.1. Mechanical Installation			 	. 3
	3.1.1. Dimensions and Weight			 	. 3
	3.1.2. Installation Location and Position			 	. 4
	3.2. Battery Stack Emulator Electrical Connections			 	. 5
	3.2.1. Getting Started			 	. 5
	3.2.2. Battery Stack Emulator Network Ports			 	. 5
	3.2.3. Connect External Network or System			 	. 6
	3.2.4. UPS Configuration			 	. 7
	3.3. Battery Stack Emulator First Power-Up			 	. 8
	3.3.1. Connect Power			 	. 8
	3.3.2. Status LEDs			 	. 9
4.	Operating Instructions				11
	4.1. External Computer Requirements				11
	4.1.1. Network Connection				11
	4.1.2. Computer OS Compatibility				11
	4.2. Using the Operator Interface				12
	4.2.1. Download and Install				12
	4.2.2. The Dashboard Tab				14
	4.2.3. The Details Tab				21
	4.2.4. The Status Banner.				29
	4.3. Using the CLI				30
	4.3.1. CLI Commands				30
	4.4. Configuring an Emulated Stack				32
	4.5. Using the Battery Stack Emulator Python Library				32
	4.5.1. Installing Python				33
	4.5.2. Battery Stack Emulator Playback				34
	4.6. Using the Battery Stack Emulator Modbus TCP Port				36
	4.6.1. Modbus TCP Addresses				37
	4.7. Using the Platform Interface				37
	4.7.1. Launch Platform Interface.				37
	4.7.2. Functions				39
	4.7.3. Networks				40
	4.7.4. Backups				42
	4.7.5. Settings				44
	4.7.6. Logs				47
	4.8. TCP Ports and Services				47
5.	Appendix A: Operating Limits				49
	5.1. Electrical Characteristics				49

	5.2. Environmental Conditions	. 4	49
	5.3. Regulatory Compliance		50
6.	Appendix B: List of Supported Equipment		51
	6.1. Supported UPS Devices		51

## 1. Introduction

Thank you for choosing Nuvation Energy.

The Battery Stack Emulator accurately emulates many core Nuvation Energy BMS product features and some of its algorithms.

## 1.1. About this Manual

This Nuvation Energy Battery Stack Emulator: Product Manual provides the following information:

- 1. Details of the emulator topology and its operation
- 2. Installation of client software and its configuration
- 3. How to use the emulator



This document applies to Battery Stack Emulator 1.0.0 software release (Firmware versions Faraday, nPlatform version 2.2.6). Content may be inaccurate or incomplete for other versions.



We thrive on your feedback and what we build is driven by your input. Please submit support tickets to <a href="mailto:support@nuvationenergy.com">support@nuvationenergy.com</a>.

## 2. Product Overview

Nuvation Energy Battery Stack Emulator provides the ability to emulate the Nuvation Energy BMS to allow early engineering development on tasks such as:

- Evaluating Battery Management System operation/configuration with a new battery model/chemistry
- Allow third-party integration with the Modbus TCP interface of the Battery Management System
- Evaluate external control management of the Battery Management System
- Evaluating Battery Management System algorithms and control with emulated system clock for real-time and faster than real-time emulation
- Use the Nuvation Energy BMS Operator Interface with the Battery Stack Emulator
- Use the Multi-Stack Controller with the Battery Stack Emulator



Figure 1. Battery Stack Emulator

The Battery Stack Emulator hosts 16 emulator instances providing the following services:

- BMS Emulator: An emulator built from the firmware of the BMS that mimics the high-level application software. Data acquisition is not included and the modelled data of the battery must be entered into the emulator.
  - Emulated BMS port for connecting an Operator Interface. This port can be used to connect the Operator Interface using a web browser.
  - Emulated BMS port for connecting to the Modbus interface of the emulated BMS. Clients can test the BMS Modbus interface using this port.
- CLI: A CLI (Command Line Interface) application to aid in high-level operation to enter emulated data into the BMS Emulator.
- HTTP API: An HTTP interface used by the Nuvation Energy provided Battery Stack Emulator Python library for controlling the emulated BMS
- Modbus TCP: A Modbus TCP interface used to enter emulated data into the BMS Emulator.

To use the Battery Stack Emulator, Nuvation Energy provides:

- CLI SSH user credentials
- Python library that provides the following capabilities

While executing the emulation, an operator can access and view the Operator Interface in their browser to observe the emulation in progress.

## 3. Installation Instructions

## 3.1. Mechanical Installation

## 3.1.1. Dimensions and Weight

The overall dimensions of the Battery Stack Emulator are 484 mm  $\times$  419 mm  $\times$  44 mm (19.1 in x 16.5 in x 1.7 in). It has a 1 U height and fits in a standard 48 cm (19 in) size server rack.

The Battery Stack Emulator module weighs 6.5 kg (14.3 lb).



Figure 2. Mechanical Drawing of Battery Stack Emulator

## 3.1.2. Installation Location and Position

The Battery Stack Emulator is rated to operate in the temperature range of 5 °C (41 °F) to 45 °C (113 °F). It is designed for indoor use.

The Battery Stack Emulator should be installed correctly into its supported size rack with no additional space required above or below the unit when mounting.

### 3.1.2.1. Mounting Clearances

A clearance of approximately 762 mm (30 in) in the back of the rack is recommended to allow sufficient space for airflow, cable connections, and access when servicing.

# ENERGY 3.2. Battery Stack Emulator Electrical Connections

## 3.2.1. Getting Started

NUVATION<sup>®</sup>

Before connecting power to the Battery Stack Emulator you need to:

- 1. Connect external network or system
- 2. UPS configuration

Below are images of the external interfaces available on the front and back of the Battery Stack Emulator.



Figure 3. Battery Stack Emulator external interfaces (front)



Figure 4. Battery Stack Emulator external interfaces (back)

## 3.2.2. Battery Stack Emulator Network Ports

Port Name	Function	Port Label	Port Speed
External	Manage network traffic external to the Battery Stack Emulator. Operator Interface is accessed from this	LAN 1	10/100/1000 Mbps
	port.	LAN 12	1/10 Gbps
Internal	Reserved for future use.	LAN 2-9	10/100/1000 Mbps
		LAN 10, 11 & 13	1/10 Gbps

#### **Table 1. Network Port Connection Map**

Figure 5, "Battery Stack Emulator port types" is an image of the Battery Stack Emulator front panel, pointing out the different types of ports the Battery Stack Emulator supports:

8x internal Ethernet ports at 10/100/1000 Mbps (LAN 2-9)

# NUVATION® ENERGY

- 2x internal Ethernet port at 1/10 Gbps (LAN 10-11)
- 1x internal SFP+ port at 1/10 Gbps (LAN 13)
- 1x external Ethernet port at 10/100/1000 Mbps (LAN 1)
- 1x external SFP+ port at 1/10 Gbps (LAN 12)



Figure 5. Battery Stack Emulator port types



The *external* and *internal* networks of the Battery Stack Emulator should remain separated and independent for the best operation of the battery pack. Excessive network traffic on the *internal* network can interfere with the Battery Stack Emulator management of devices on the internal network.

### 3.2.3. Connect External Network or System

The Ethernet RJ45 port labelled 1 or the SFP+ port labelled 12 may be used to connect the Battery Stack Emulator to an external system, such as:

- Energy control systems, such as PCSs and energy controllers
- A laptop, to configure operating parameters and observe status
- A local area network (LAN) connection, for wired internet access
- An Ethernet switch, to access any number of the above devices

The External Ethernet interface is a standard Cat5e-rated RJ45 jack, supporting only 10, 100, and 1000 Megabit speeds. Any Cat5e-rated or higher Ethernet cable of suitable length may be used to connect to this RJ45 jack.



Connecting both ports 1 & 12 at the same time will create a loop and will cause interference with the operation of the external network.

No connection should be made to the IPMI port unless directed by Nuvation Energy.

Refer to the network port connection map Table 1, "Network Port Connection Map".

A typical networking configuration for an Battery Stack Emulator is demonstrated below.

# NUVATION® ENERGY



Figure 6. Typical networking configuration for an Battery Stack Emulator

## 3.2.4. UPS Configuration

An uninterruptible power supply (UPS) is a device that allows connected equipment to continue running when incoming power is temporarily interrupted. A UPS also allows for the safe, orderly shutdown of the connected equipment by providing protection from instantaneous power disruptions.

The Battery Stack Emulator provides support for an external UPS that can be plugged into the USB 3.0 or Ethernet ports. Refer to Figure 3, "Battery Stack Emulator external interfaces (front)" for the location of USB ports. The list of compatible UPS devices can be found in <u>Appendix B</u>. Only UPS devices which can connect via USB or Ethernet are supported.

Support for UPS includes the following features:

- Auto shutdown : When the UPS is running on battery, and it reaches the critical low battery level, the UPS will initiate a shutdown procedure. This procedure will trigger the connected Battery Stack Emulator to gracefully shut down before UPS shuts off power
- Timeout : This feature allows the Battery Stack Emulator to operate on battery mode for a configurable period of time and then automatically power off the connected UPS alongside a graceful shutdown. This is useful when some UPS capacity should be reserved for a black start of the system. In a black start scenario, the Battery Stack Emulator UPS should be connected to the energy storage system to ensure the UPS can maintain continuous operation after black start of the energy storage system.

Please reach out to <u>support@nuvationenergy.com</u> for support on configuring UPS device with Battery Stack Emulator. The UPS features cannot be configured directly and will work with default settings as specified during the ordering process.

## 3.3. Battery Stack Emulator First Power-Up

## 3.3.1. Connect Power

#### Identify an appropriate AC power source

An IEC 320-C13 cable is required to connect the AC power source to the back of a unit. In addition, the AC power source must not be derived from the energy system itself without the ability to maintain (or turn on) the supply when the energy system is powered off (i.e. black start).

An external UPS can be used between the energy system-derived AC source and the supply providing power to the Battery Stack Emulator when an external AC power source is not available.

#### Powering up the system

Verify that all the mechanical and electrical installation steps are completed. In addition, check if the Battery Stack Emulator is properly connected to the network, and power.

When ready to power on the Battery Stack Emulator, connect an IEC 320-C13 cable to the unit and then enable AC power. The Battery Stack Emulator turns on automatically when power is applied; however, following a shutdown, the power button can be used to manually turn on the Battery Stack Emulator as an alternative method to simply power-cycling the device.

The Battery Stack Emulator will emit a 4-tone startup chime when low-level software has started. This will be followed by a 3-tone chime once all software has been initialized. The Nuvation Energy user interface will be accessible shortly after this chime.

To shutdown the system, momentarily press the power button to initiate a graceful shutdown of the Battery Stack Emulator. A graceful shutdown is always recommended before unplugging the power supply.

0

The Battery Stack Emulator initiates a factory restore after 10 sequential unsuccessful boot sequences. To avoid this situation, ensure that the unit is fully powered up before power cycling.

In the event the unit has initialized a factory restore, please contact <u>support@nuvationenergy.com</u> to bring the unit back to a functional state.

# NUVATION® ENERGY

## 3.3.2. Status LEDs

When the Battery Stack Emulator is powered up, its status LEDs provide indication of the functional status of the module and its interfaces. The Operator Interface provides additional information.

Figure 7, "Battery Stack Emulator LED Descriptions" and Table 2, "Port LEDs Description" describe the LEDs present on the Battery Stack Emulator with their corresponding status and descriptions.



#### Figure 7. Battery Stack Emulator LED Descriptions

#### Table 2. Port LEDs Description

LED	Colour	Status
Informational LED	Solid Red	Battery Stack Emulator Overheating
	Flashing Red	Battery Stack Emulator: Fan Failure
NIC2 LED	Flashing Green	LAN2: Active
NIC1 LED	Flashing Green	LAN1: Active
HDD LED	Flashing Orange	Battery Stack Emulator: Hard Drive Activity
Power LED	Solid Green	Battery Stack Emulator: Operational
IPMI Activity (A0)	Flashing Orange	IPMI Speed: 10/100 Mbps
	Flashing Green	IPMI Speed: 1 Gbps
IPMI Link (L0)	Solid Orange	IPMI State: Active
LAN1 Activity (A1)	Flashing Orange	LAN1 Speed: 10/100 Mbps
	Flashing Green	LAN1 Speed: 1 Gbps
LAN1 Link (L1)	Solid Orange	LAN1 State: Active
LAN2 – LAN9 Activity (A2 – A9)	Flashing Green	LAN# Speed: 10/100 Mbps
	Flashing Orange	LAN# Speed: 1 Gbps

Nuvation Energy Battery Stack Emulator - Product Manual

LED	Colour	Status
LAN2 – LAN9 Link (L2-L9)	Solid Orange	LAN# State: Active
LAN10 – LAN 13 Activity (A10-A13)	Flashing Orange	LAN# Speed: 1 Gbps
	Flashing Green	LAN# Speed: 10 Gbps
LAN10 – LAN13 Link (L10-L13)	Solid Orange	LAN# State: Active

## 4. Operating Instructions

## 4.1. External Computer Requirements

An external computer, like a laptop or a PC, is required to perform the setup steps. Ensure the following requirements have been met when selecting a computer.

## 4.1.1. Network Connection

It is recommended to connect the computer to the same network as the *External Ethernet* on the Battery Stack Emulator. The default settings for the *External Ethernet* are DHCP, and requires the network to have an active DHCP server. Most corporate networks and routers will have a DHCP server.

If a DHCP capable network is not available, (i.e. if the computer must be connected directly to the Battery Stack Emulator via an ethernet cable) it is recommended to initially connect to one of the *Internal Ethernet* ports. The Battery Stack Emulator has a static IP default on the *Internal Ethernet* network with the following settings:

- Static IP: 192.168.1.10
- Net mask: 255.255.255.0

Ensure the computer networking is configured with a static IP of 192.168.1.x where x cannot be 0, 10 or 255 to enable communication with the Battery Stack Emulator. It is recommended once the initial connection has been made, to configure the *External Ethernet* port to the desired settings and connect the computer to that network rather than using the *Internal Ethernet*. See <u>Section 4.7.3</u>, "<u>Networks</u>" for details on configuring network settings.



An internet connection is not required for the product to function. However it does use the Network Timing Protocol (NTP) to maintain its clock accuracy.

## 4.1.2. Computer OS Compatibility

Ensure the Operating System of the laptop/computer supports multi-cast DNS (mDNS).

	1 57 11	
OS	Version	Additional Software Required
Windows	10	N/A
Windows	8 and lower	Apple Bonjour
MacOS	10.2 and higher	N/A
Linux	N/A	Avahi

#### Table 3. Operating Systems that support mDNS



mDNS is also operational when a Static IP is configured.

# NUVATION® ENERGY

#### Manual IP Discovery

In the event that the computer does not support mDNS, the MAC address for the external network port is labeled on the exterior of the Battery Stack Emulator.

Look for this MAC address in the DHCP server to determine which IP address was assigned to the Battery Stack Emulator and navigate to 'http://<ip-address>' from a compatible web browser rather than the mDNS URL <a href="http://ncontroller-</a>

## 4.2. Using the Operator Interface

The Battery Stack Emulator Operator Interface provides an interface to the stack as it would for the real Stack Switchgear hardware. To connect the Operator Interface to the first emulated BMS, use the connection information: <u>http://<ip\_address>:8000</u>, where the <ip\_address> is the IP address of the Battery Stack Emulator or the mDNS hostname ncontroller-<serial\_number>.local. Some specific examples of the connection information to be used in the Operator Interface are listed below for the first emulated BMS at port 8000 (see <u>Table 8</u>, "Battery Stack Emulator TCP Ports and Services for <u>Stack 'n'"</u> for Operator Interface ports on emulated BMSs other than the first):

- Using IP 192.168.1.10: <u>http://192.168.1.10:8000</u>
- Using mDNS for product serial number 12345678: <u>http://ncontroller-12345678.local:8000</u>

Not all operations are supported when using the Operator Interface to access the Battery Stack Emulator. The unsupported features and operations are defined in the list below.



Firmware upgrades are not supported through the Operator Interface. To upgrade the Battery Stack Emulator, please refer to <u>Section 4.7.5.1</u>.



Networking can not be updated through the Operator Interface. To update the network information, please refer to  $\frac{\text{Section 4.7.3}}{\text{Section 4.7.3}}$ .



Entering Service Lockout through the Operator Interface is not supported. If Service Lockout is entered, it can not be exited again without re-uploading the stack configuration or restarting the Battery Stack Emulator.



Open wire detection is not supported through the Operator Interface on the Battery Stack Emulator.



Configuration files cannot be uploaded through the Battery Stack Emulator Operator Interface. Battery Stack Emulator configuration must be done using the web endpoint <u>http://<ip\_address>:53000/upload-config</u> as described in <u>Section 4.4</u>

## 4.2.1. Download and Install

The Operator Interface is used to access the Battery Stack Emulator. It must be installed on a local



PC and will accesses the BMS over a network connection.

#### Download

Visit <u>https://www.nuvationenergy.com/technical-resources</u> to download the latest version of the Operator Interface.

#### Install

Extract the contents of bms-oi-<version>.zip to a suitable location on your computer. To avoid overwriting other releases or files present in the same directory it is recommended to extracting the package to a folder with the same name as the package.

## 4.2.2. The Dashboard Tab

The default tab of the Operator Interface is the Dashboard. The Dashboard contains a high-level overview on the state of the battery stack. This is the only page required for daily monitoring of the battery stack.



Figure 8. Nuvation Energy BMS Operator Interface Dashboard screenshot

### 4.2.2.1. Warnings and Faults

Before going into the details of the gauges and information presented in the dashboard, it is important to understand what a fault and a warning Nuvation Energy BMS status means.



### 4.2.2.2. Stack Voltage

The stack voltage radial meter shows the total battery stack voltage.





### 4.2.2.3. Stack Current

The stack current radial gauge shows the battery stack current as well as the maximum charge current limit and the maximum discharge current limit. The acceptable current range is visualized on the gauge by the blue arc. An absence of the blue arc indicates the battery stack cannot be charged or discharged in its present condition.

A negative current value indicates the battery stack is charging. A positive current value indicates the battery stack is discharging.



### 4.2.2.4. State-of-Charge

The State-of-Charge radial gauge shows the battery stack's State-of-Charge. The battery stack is empty when the State-of-Charge value is 0% and full when the State-of-Charge value is 100%.



### 4.2.2.5. Depth-of-Discharge



The Depth-of-Discharge radial gauge shows how much energy has been taken out of the battery stack. In an ideal Energy Storage System, defined as a system with no power losses, the amount of energy shown in this gauge needs to be added back into the battery stack to fill it back up to 100% State-of-Charge.



### 4.2.2.6. Cell Voltage

The cell voltage bar gauge shows the maximum, minimum, and average cell voltage measurements within the stack.

The high cell voltage and low cell voltage warning and fault threshold is visualized on the gauge with yellow and red segments. The blue segment depicts the acceptable cell voltage range.

If a triangle enters the yellow segment, a warning has occurred. If a triangle enters the red segment, a fault has occurred.

The maximum and minimum cell location in the stack and their voltage values are shown below the gauge, along with the average cell voltage value.

#### **Cell Voltage**



### 4.2.2.7. Temperature

The temperature bar gauge shows the maximum, minimum, and average cell temperature measurements within the stack.

The high cell temperature and low cell temperature warning and fault threshold is visualized on the gauge with yellow and red segments. The blue segment depicts the acceptable cell temperature range.

If a triangle enters the yellow segment, a warning has occurred. If a triangle enters the red segment, a fault has occurred.

The maximum and minimum cell location in the stack and their temperature values are shown below the gauge, along with the average cell temperature value.

#### Temperature



### 4.2.2.8. Nuvation Energy BMS Status

Nuvation Energy BMS status information contains information on the overall safety status of the battery stacks, the battery stack connection state, number of cells balancing, maximum charge current limit, maximum discharge current, and the time and date of the last update of the Dashboard.

#### 4.2.2.8.1. Operation Status

Nuvation Energy BMS operation state is shown in the big status circular indicator.

# NUVATION® ENERGY



Figure 9. Three possible Nuvation Energy BMS operation states

The normal state is All OK and the color of the indicator will be green. The warning state is Warning and the color of the indicator will be orange. The fault state is Fault and the color of the indicator will be red.

Clicking on the indicator will jump to a comprehensive status list of warnings and faults active in the battery stack.

Clicking on the Clear button below the state will cancel any warnings and faults that are not self-clearing.

#### 4.2.2.8.2. Connection State

The battery stack connection state is shown in the oval indicator.



**Figure 10.** Three possible connection states

Stack Disconnected in a red oval indicates the SSG contactors are open, and the battery stack is unavailable to be charged or discharged.

Stack Pre-charging in an orange oval indicates the battery stack has connected its pre-charge circuit and is attempting to equalize the battery stack voltage to the system DC bus voltage.

Stack Connected in a green oval indicates the battery stack is available to be charged or discharged.

Clicking the Connect button initiates the stack connection sequence of events. Nuvation Energy BMS must be in the All OK state for the Connect button to be available.

Clicking the Disconnect button will disconnect the battery stack from the system DC bus.

#### 4.2.2.8.3. Information Table

The information table shows the number of cells that are having excess energy bled off to maintain a balanced battery stack.



Name	Value
Cell Balancing	15
Charge Limit	7.00 A
Discharge Limit	8.00 A

The Charge Limit shows the maximum charge current limit value. The Discharge Limit shows the maximum discharge current limit value.

The Charge Limit and Discharge Limit values are visualized on the Stack Current radial gauge as the limits of the blue arc.

#### 4.2.2.8.4. Last Update

The Updated time and date shows the last time the Operator Interface had successfully communicated with Nuvation Energy BMS and updated all items in the Dashboard with values from Nuvation Energy BMS. The time and date is based on the local computer/tablet; it does not come from Nuvation Energy BMS.

If the communication with a Nuvation Energy BMS is lost, a notification banner appears at the top of the display screen. The information shown on the Dashboard represents the last data received and is no longer recent.

## 4.2.3. The Details Tab

The Details tab contains a much more detailed view into the status of Nuvation Energy BMS. The data values shown in this tab can be easily copied into a spreadsheet as a means of capturing the current state of Nuvation Energy BMS for manual data recording purposes.

The Details tab has multiple sub-sections called *accordions* that can be expanded to reveal more information. You can have multiple accordions expanded at the same time.

Nuvation En	ergy BMS	Dashboard	Details	8	<b>\$</b> -
Battery					~
Contactor Life					~
SOC Calibration					~
Safety					~
Cell Voltages					~
Thermistor Temp	beratures				~
Open Wire					~
Resistance					~

**NUVATION@ENERGY** 

() SUPPORT

#### Figure 11. Nuvation Energy BMS Operator Interface Details tab screenshot



#### Figure 12. Operator Interface Support Button



The SUPPORT button can be used to direct the operator to the Nuvation Energy website to contact Support.

### 4.2.3.1. Battery

The Battery accordion contains values on the overall battery stack and the maximum charge current limit, the maximum discharge current limit, and the number of cells balancing in the battery stack. This information is identical to the values shown in the radial gauges, the bar gauges and the

#### Information Table on the Dashboard.



Figure 13. Battery accordion in Details Tab

### 4.2.3.2. Contactor Life

The Contactor Life accordion contains values that track the life of contactors. See Contactor Life Tracking for further information.

Contactor Life	^
	Updated 2024-06-04, 2:51:52 p.m.
Contactors	Remaining Life
Contactor 0	100%
Contactor 2	100%



### 4.2.3.3. SoC Calibration

The State of Charge Calibration accordion allows for calibration of SoC and reset of the measured capacity estimate. This accordion is only visible if the OCV is enabled (stack\_soc.ocv\_enabled). Both of these operations are only enabled when the battery is operational (not in service lockout) but disconnected (stack\_control.actual\_state == 0).

#### SOC Calibration

Battery Charge		Battery Capa	acity
State of Charge	67 %	Measured Capacity	0.000 Ah
Depth of Discharge	0.150 Ah	Nameplate Capacity	1.500 Ah
Calibrate		Reset	
SOC is calibrated from using the open-circuit	n cell voltages voltage curve.	Capacity is reset to stac rating while accounting	k nameplate
Battery contactors	must be	imbalance. Battery conta disconnected to	ctors must be reset

Figure 15. SoC Calibration accordion in Details Tab

#### 4.2.3.3.1. Charge Calibration

SoC charge calibration resets the SoC based on the open-circuit voltage curve. More specifically, it uses the measured voltage in the cell and the OCV curve to calculate a cell level SoC estimate. The SoC estimates are aggregated to determine the stack level SoC that is seen on the dashboard. Since the SoC calibration uses the OCV, the curve needs to be enabled.

A user can reset the SoC only if the stack is disconnected. For chemistries like LFP, it is also beneficial to wait 1 hour after disconnection before resetting the SoC. This will allow the battery to relax and reach equilibrium before a reset calculation is conducted. Although it is recommended to wait 1 hour, the period is not enforced on the Operator Interface.

The SoC reset is used to provide a rough initial estimate of SoC before a calibration can occur. This is usually when the BMS is initially connected and setup up. It should not be used as a replacement for SoC calibration, which can be done by charging the battery to FULL.

#### 4.2.3.3.2. Capacity Reset

Capacity calibration resets the SoC to the nominal capacity. Note that if the stack is imbalanced, it will update the nominal capacity to account for this imbalance. This is done by calculating the SoC for each cell.

The recommendations for SoC calibration described above can be followed here as well for determining when to do a capacity reset.

The user should reset the capacity if the measured capacity value is significantly different from the nominal capacity and the battery degradation is known. Once again, the reset provides a rough capacity estimate. The ideal approach for determining measured capacity is to conduct a charge to FULL and a discharge to EMPTY calibration cycle.

### 4.2.3.4. Safety

The Safety accordion contains a comprehensive list of all possible Nuvation Energy BMS faults,

warnings and user triggers as well as the overall status of the battery stack. An active fault is shown as Tripped. An active warning or user trigger is shown as Triggered. A fault, warning or user trigger that has not completed its Self Check is shown as Checking. In normal operation, all user triggers, warnings and faults should be Clear.

▼ Safety		
		Last update: Fri Mar 25 2022 17:25:44 GMT-0400 (Eastern Daylight Time)
Name	State 🕈	Trigger
Stack Under Voltage Fault	Clear	stack_fault_voltage_under
Stack Over Voltage Fault	Clear	stack_fault_voltage_over
Stack Low Voltage Fault	Clear	stack_fault_voltage_lo
Stack High Voltage Fault	Clear	stack_fault_voltage_hi
Cell Under Voltage Fault	Clear	stack_fault_cell_under
Cell Over Voltage Fault	Clear	stack_fault_cell_over
Cell Low Voltage Fault	Clear	stack_fault_cell_lo
Cell High Voltage Fault	Clear	stack_fault_cell_hi
Discharge Under Temperature Fault	Clear	stack_fault_discharge_therm_under
Discharge Over Temperature Fault	Clear	stack_fault_discharge_therm_over

Figure 16. Safety accordion in Details Tab

Clicking on the Clear Faults and Warnings button at the bottom of this accordion will clear any faults and warnings that are not self-clearing. The Clear button on the Dashboard can also be used.

Stack Older Yolaye Lockout		Citical	อเลงก_นขม_อเลงก_ชมแลมูอ
Cell Under Voltage Lockout		Clear	stack_uvlo_cell_voltage
Discharge High Current User		Clear	stack_trig_discharge_current_hi
Charge High Current User		Clear	stack_trig_charge_current_hi
Discharge Low Temperature User		Clear	stack_trig_discharge_therm_lo
Discharge High Temperature User		Clear	stack_trig_discharge_therm_hi
Charge Low Temperature User		Clear	stack_trig_charge_therm_lo
Charge High Temperature User		Clear	stack_trig_charge_therm_hi
Stack Low Voltage User		Clear	stack_trig_voltage_lo
Stack High Voltage User		Clear	stack_trig_voltage_hi
Cell Low Voltage User		Clear	stack_trig_cell_lo
Cell High Voltage User		Clear	stack_trig_cell_hi
Stack Controller Configuration Consistency Check Fault		Clear	sc_fault_config
Clear Faults and Warnings	Generate Report		

#### Figure 17. Bottom of Safety accordion in Details Tab

Clicking on the Generate Report button at the bottom of this accordion will generate a safety report JSON file with a list of the Nuvation Energy BMS faults and warnings and their current state as well as the current firmware versions.

### 4.2.3.5. Cell Voltages

The Cell Voltages accordion lists voltage measurements for all Cells configured in the Configuration file. Cells that are not configured are displayed as a - (hyphen). Voltages in red indicate measurements which have triggered a Nuvation Energy BMS fault. Voltages that are highlighted in yellow are open wires. There is no differentiation between cells that are in the normal operating voltage range and cells that have triggered a Nuvation Energy BMS warning. There is also no indication of which particular cells are currently being balanced by the BMS.

T Cell Vol	ages																
Filler. Off	Above Below											Last upd	ate: Fri Mar 25	2022 16:21:03	GMT-0400 (Eas	tem Daylight Ti	lme)
	Cell 1	Cell 2	Cell 3	Cell 4	Cell 5	Cell 6	Cell 7	Cell 8	Cell 9	Cell 10	Cell 11	Cell 12	Cell 13	Cell 14	Cell 15	Cell 16	
CI 1	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	10	355	85		
CI 2	3 333 V	3 333 V	3.333 V	3.333 V	3 333 V	3 333 V	3.333 V	3.333 V	3 333 V	3.333 V	3.333 V	3 333 V	-				
CI 3	3.333 V	3.333 V	3.333 V	3.333 V	3 333 V	3.333 V	3 333 V		(23)	st (	12						
CI 4	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	-	870	10		
Ct 5	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	8	121	12 V	12	
CI 6	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V		14		2	
CI 7	3.333 V	3 333 V	3.333 V	3.333 V	3.333 V	3 333 V	3.333 V	3.333 V	3 333 V	3 333 V	3.333 V	3 333 V	13	(43)	34 <sup>1</sup>	8	
CI 8	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	3.333 V	-			-	

Figure 18. Cell Voltages accordion in Details Tab

* Cell voltages																
Filter: Cif Above Legend: Open With	Below 19												1 504 1	pelais: Wee Nov 20 20	IN DRIVENS OF CMT-18500	(Fester: Speated Time)
	Cd 1	Oct 2	Cels	Cd 4	0:15	Cc18	Cel V	Gel a	Oct 9	Oct 10	Cell 11	Gell 12	03115	Cel 14	Oct 15	QUE 16
GI 1	3 333 V	3.333 V	V SZELE	3 353 V	s.ssa V	¥ SZE.E	3 3 3 V	3.325 V	3.334 V	V ISES	X 394 V	3.383 V	10	12		15
GI2	3.334 V	3.303 V	9.399 V	0.034 V	3.393 V	0.200 V	9.839 V	3.333 V	3.393 V	9.939 V	3.034 V	3.394 V				
GLS	3 334 V	3.3213 V	3.334 V	3 333 V	3.33H V	3.333 V	3 333 V	3.335 V	3.334 V	3 334 V	3.384 V	3.334 V	84	82	12	92 - L
CI4	3.929 V	3.393 V	9.534 V	3.939 V	3.383 V	9.399 V	9.932 V	3.983 V	8.385 V	9.939 V	3.932 V	3.384 V				
CIS	3 334 V	1.3(19 V	3.334 V	3 332 V	3.313.9	3.333 V	a asa V	3.303 V	3.333 V	a ana v	3 312 V	3.333 V		82	14 A	
CIE	3.853 V	3.383 V	9.932 V	8.939 V	3.393 V	8.382 V	8.838 V	3.393 V	8.384 V	8.839 V	3.985 V	3.382 V		<u></u>	14 A	÷
C(7	3 334 V	3.333.9	3.330 V	3.332 V	3.334 V	3.333 V	3 333 V	3.333 V	3.333 V	3 333 V	5 303 V	3.333 V				
CIS	3.858 V	3.394 V	3.339 V	3,334 V	3.383 V	3.339 V	3 332 V	3.384 V	3.383 V	3 3 3 9 V	3.393 V	3.385 V	24			1

Figure 19. Cell Voltages with open wires accordion in Details Tab

### 4.2.3.5.1. Filtering

You can filter the display to highlight cells with voltages above or below a value you specify. The values that match the criteria will be bolded and all other values will be faded.

ter of the	n Pera 1816	y.						
	5N(1	DAL7	CALL.	CALL	Cellő	C#05	DE T	EAL F
011	7.127.1	3.522.4		3.173 V	3.163 V	3.165 V	1.150 V	3.173 V

### 4.2.3.6. Thermistor Temperatures

The Thermistor Temperatures accordion lists temperature measurements for all Thermistors configured in the Configuration file. Thermistors that are not configured are displayed as a dash. Temperatures in red indicate measurements which have triggered a Nuvation Energy BMS fault. There is no differentiation between thermistors that are in the normal operating temperature range and thermistors that have triggered a Nuvation Energy BMS warning.

## NUVATION® ENERGY

\* Thermister Temperatures

Filter: Off Above Below

Last update: Fri Nov 29 2019 12:50:06 GMT-0500 (Eastern Standard Time)

	Index 1	Index 2	Index 3	Index 4	Index 5	Index 6	Index 7	Index 8
CI 1	27 °C	27 °C	27 °C	26 °C	27 °C	27 °C		70
CI 2	27 °C	27 °C	28 °C	27 °C	28 °C	27 °C		•0
CI 3	26 °C	26 °C	27 °C	27 °C	27 °C	27 °C	145 1	21
CI 4	27 °C		5:					
CI 5	28 °C	27 °C	*	-8				
CI 6	27 °C	27 °C	27 °C	28 °C	27 °C	27 °C	*	÷
CI 7	26 °C	26 °C	26 °C	27 °C	27 °C	27 °C	8	53
CI 8	27 °C	27 °C	27 °C	28 °C	27 °C	27 °C	-	

#### Figure 20. Thermistor accordion in Details Tab

#### 4.2.3.6.1. Filtering

You can filter the display to highlight cells with temperatures above or below a value you specify. The values that match the criteria will be bolded and all other values will be faded.



### 4.2.3.7. Open Wire



Open wire detection is not supported through the Operator Interface on the Battery Stack Emulator. The following section describes the section as it pertains to the G5 High-Voltage BMS.

The Open Wire accordion lists open wire diagnostics for all Cells configured in the Configuration file. Cells that are not configured are displayed as a - (hyphen). Diagnostic data that is highlighted in yellow indicates an open wire.

Open Wire

Acquire Open Wire Ratios

Press button to start retrieving the ratios.

#### Figure 21. Open Wire accordion in Details Tab

To trigger diagnostics on all cells, click the "Acquire Open Wire Ratios" button. Once clicked, the open wire scanning process begins.

▼ Open Wire

Acquire Open Wire Ratios

Starting to scan... Elapsed Time: 4s

#### Figure 22. Open Wire acquiring accordion in Details Tab

# NUVATION® ENERGY

Once the open wire scanning has completed and all diagnostics data is collected it is displayed in a tabular format with open wires highlighted in yellow.

* Open Wine													( and	adate The New Of Co.		Exclusion Strends and Trans-
Acquire Open w Buccess getting op	ite Ratios co wre fates												Lass	ipeane. The Nor 21 pe	19 10 07 01 061 10 000	East Sandad Inter
Filer CH Acove Legend Ocer Was	e Delow et															
	Cell	CH 2	Cell 3	Cell 4	Cel 5	Ce16	0617	Cel 8	Cel 9	Cel 10	Cel 11	Cel12	Cel 13	Cel 14	Cel 15	Cell 16
GH	0.920	0.921	0.922	0.922	0.919	0.91Đ	0.821	0.920	0.920	0.921	0.016	0.920				
CI2	0.999	C 9973	6.924	0.524	0.924	0.925	0.995	d 925	8,824	0.825	3,993	0.9671	12	141	14	14
CIS	0.920	0.920	0.922	0.924	0.924	0.923	0.923	0.924	0.925	0.924	0.922	0.920	10	(÷)	84	14
C(4	0.822	0.923	6.521	0.924	0.924	0.823	0,823	6.923	0.523	0.823	0.974	0.883				
CI 5	0.925	C.022	0.325	0.927	0.922	0.922	0.5920	0.890	0.322	0.921	0.920	0.990	82	200	19	38
CIE	0,905	0.905	0.908	0.908	0.929	0,908	0.909	0.908	0,908	0.900	0.926	0,907				
CLT	0.910	0.012	0.912	11.8.12	0.930	0.910	0.912	0.012	0.012	0.812	0.9=2	0.910	÷0	300	07	33
CIS	0.910	0.911	0.913	0.914	0.915	0.915	0.914	0.901	0.902	0,916	0.914	0.914	+0	(*)	()÷	

#### Figure 23. Open Wire diagnostics accordion in Details Tab

The diagnostic values displayed are ratios of Voltage. Values very close to one ( > 0.97) indicate a short condition. Values approaching zero (0.0 to 0.4) indicate an open wire connection.

#### 4.2.3.7.1. Filtering

Use the filter to highlight ratios of Voltage that are above or below the specified value. The values that match the criteria will be bolded and all other values will be faded.

Fiter Off /	Above Below	0.9						
	Cel 1	Cel 2	Cell 3	Cell4	Cel 5	Cel 6	Cell 7	Cell 8
CI 1	0.900	0.920	0.600	0.900	0.920	0,990	0.000	0.000-

### 4.2.3.8. Resistance

#### **Resistance accordion in Details Tab**

The Resistance accordion contains cell resistance estimate values of every installed cell. This accordion is only visible if the cell model estimator is enabled (stack\_cell\_model\_estimator.enabled). See Cell Resistance Estimation for further information.

Filtering is available for resistance values. Use the filter to highlight resistance values that are above or below the specified value. The values that match the criteria will be bolded and all other values will be faded.

Resistance

Filter: Off Above Below

Updated 2024-05-30, 10:17:30 a.m.

^

	Cell 1	Cell 2	Cell 3	Cell 4	Cell 5	Cell 6	Cell 7	Cell 8	Cell 9	Cell 10	Cell 11	Cell 12	
CI 1	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	^
CI 2	-	-	-	-	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	
CI 3	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	-	-	-	-	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	
CI 4	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	-	-	-	-	
CI 5	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	
CI 6	12	-	-	-	<mark>0.300</mark> mΩ	<mark>0.300</mark> mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	
CI7	0.300 mΩ	0.300 mΩ	0.300 mΩ	0.300 mΩ	-	-	-	-	-	). <del></del> )	-	-	

Figure 24. Resistance accordion in Details Tab

## 4.2.4. The Status Banner

The banner at the top of the screen is used to indicate high level changes in system status. During typical operation nothing is displayed and this indicates the Operator Interface is communicating with the BMS and the BMS is fully operational with no major diagnostics problems.

## 4.2.4.1. Service Lockout Indication



The Battery Stack Emulator should never be in service lockout. If service lockout is entered through the Operator Interface, it can only be exited with by re-uploading the stack configuration.

When the system is either entering or is in service lockout, a banner is displayed indicating this to the user.

Service Lockout

#### Figure 25. Operator Interface Service Lockout indicator

Entering Lockout

#### Figure 26. Operator Interface Entering Service Lockout indicator

### 4.2.4.2. Self Check Indication

When the system is either exiting service lockout or has just booted, the system will execute a Self Check to verify a safe operation. A banner is displayed indicating the Self Check execution to the user.



#### Figure 27. Operator Interface Self Check indicator

### 4.2.4.3. Communication Loss

When the Operator Interface can no longer communicate with the Battery Management System, a communication lost banner is displayed at the top of the display. It will provide the amount of time since disconnected and updates each second.

## Communication to BMS lost: Data last updated 4 seconds ago

#### Figure 28. Operator Interface Communication lost indicator

## 4.3. Using the CLI

To connect to the first instance (i.e. the first stack) of the Battery Stack Emulator CLI, run ssh -p 50022 sim@<ip-address> from a command shell (CMD, PowerShell, or bash, depending upon which approach you are using). The SSH username is sim and the password is provided by Nuvation. You should see the following:

+	+
Battery Stack Emulator (BSE)	i i
Copyright © Nuvation Research Corporation. All rights reserved.	i
Proprietary and Confidential: Use permitted only under NDA.	i
+	+
Loading /opt/battery stack emulator/g5 simulated stack register con	fig.txt
Running with 1s time step	-
BSE>	

Figure 29. Battery Stack Emulator CLI

The Battery Stack Emulator prompt can be used to initialize the emulator and perform basic operations. For connecting with other emulated BMS instances, see <u>Table 8</u>, "<u>Battery Stack Emulator</u> <u>TCP Ports and Services for Stack 'n'"</u> for CLI SSH ports on emulated BMSs other than the first.

## 4.3.1. CLI Commands

The Battery Stack Emulator CLI (Command Line Interface) can be used to perform basic operations such as setting voltages, temperatures and current as well as connecting/disconnecting the battery stack. Below is a summary of the commands available for use:

- run: free-running clock mode
- stop: stopped/stepped clock mode
- step: step clock
- set cell: set cell voltages
- set therm: set thermistor temperatures
- set dc: set current
- batt clear: clear faults
- batt connect: connect contactors
- batt disconnect: disconnect contactors

### 4.3.1.1. Clocking Commands

The Battery Stack Emulator relies on a clock signal to execute processing for a single time-step and update outputs based on battery measurement inputs. Emulation time may be clocked in a continuous, free-running fashion. On startup, the Battery Stack Emulator will initially run in free-running mode. In this mode, the resulting behavior closely resembles a running BMS.

The Battery Stack Emulator may be stopped at any time with the stop command:



BSE> stop

When emulation has been stopped with the above command, emulation time may also be clocked one cycle at a time. In this mode, the resulting behavior is more like a single-step debugger where inputs can be changed and outputs examined at each individual time step:

BSE> step <timestep>

where <timestep> is the optional time step size in seconds, which defaults to 1 second.

The run command is used to resume the free-running mode:

BSE> run

### 4.3.1.2. Set Commands

Cell voltages, thermistor temperatures, and stack current may be set to arbitrary values using the set command. If the emulator is not in free-running mode, simply setting a measurement does not cause the Battery Stack Emulator to use the new value(s) immediately. The emulator clock must first be advanced as described in <u>Section 4.3.1.1</u>.

To set installed cell voltages between 3.2 and 3.3 V:

BSE> set cell 3.2 3.3

To set installed thermistor temperatures between 28 and 29 °C:

```
BSE> set therm 28 29
```

Note when the two arguments are given following cell or therm, the Battery Stack Emulator assigns random values between the two points. If only a single value is given, it sets all inputs to the same value.

To set DC current to a constant current of 5 A:

BSE> set dc cc 5

### 4.3.1.3. Battery Commands

The usual battery commands to connect, disconnect, and clear faults are available through the batt command. These operations can also be initiated from the Operator Interface.

To clear latched faults:

BSE> batt clear



To connect the battery stack:

BSE> batt connect

To disconnect the battery stack:

BSE> batt disconnect

### 4.3.1.4. Exiting the CLI

The CLI can be exited using the CTRL + C and CTRL + D key combinations after a simulation session is finished. When exited in this manner, the Battery Stack Emulator instance will be terminated and restarted.

If using an openssh client, the CLI can be exited using the following escape sequence from the emulator prompt.

BSE> \*ENTER\*

This sequence will leave the emulator running but terminate the SSH connection. Due to the nature of the PuTTY client, this sequence will not terminate connection from sessions using that client.

## 4.4. Configuring an Emulated Stack

The Battery Stack Emulator is provided with a default configuration. In the case another configuration file is required, it can be uploaded to the Battery Stack Emulator using the following command:

curl --location 'http://<ip\_address>:53000/upload-config' --form 'file=@<file\_location>'

where ip\_address is the address of the Battery Stack Emulator and file\_location refers to the location of the desired configuration.

For more details about the configuration format and customizations, please refer to the relevant sections of the Stack Switchgear Product Manual.

### 4.5. Using the Battery Stack Emulator Python Library

The provided python library and playback script may be used to communicate with the Battery Stack Emulator. This python library and supporting files are provided by Nuvation Energy in a 'zip' file. The following diagram shows the entire emulator process of the Battery Stack Emulator with the Python library:



#### Figure 30. Python Library Overview

This playback script requires an external PC on the same network as the Battery Stack Emulator with Python installed. The summary of how the library is intended to be used is:

- 1. Connect to the emulated BMS instance to a python application
- 2. At each emulated clock cycle, data for the battery is input into the Battery Stack Emulator. Simulated battery data is provided by the client.
- 3. After the clock update, a list of BMS registers is read from the BSE. The list of registers is configurable by the client.
- 4. The output data is provided using a python key/value map where the key is the BMS register name.

Users of the emulator would develop software that at each emulated clock cycle would do the following:

- 1. Translate the output BMS registers into their proprietary data structures.
- 2. Input these data structures into their proprietary algorithm software.

These software components are shown in <u>Figure 30, "Python Library Overview"</u> as the Proprietary Software blocks.

## 4.5.1. Installing Python

The Battery Stack Emulator has been tested on python3 version 3.8, though other python versions might also work. If python3 is not already installed, it can be downloaded from the link: <a href="https://www.python.org/downloads/">https://www.python.org/downloads/</a>

In addition to Python3, the following python libraries are required:



- requests==2.28.1
- pandas==1.4.0
- numpy==1.24.4

The libraries can be installed using the package manager pip with the commands below:

- python3 -m pip install requests==2.28.1
- python3 -m pip install pandas==1.4.0
- python3 -m pip install numpy==1.24.4

Once python and the libraries are installed, unpack the provided 'zip' file from Nuvation Energy with the python library for the Battery Stack Emulator in a folder on the external PC.

## 4.5.2. Battery Stack Emulator Playback

In your given package, you will find the python library for interacting with an emulator instance. This library is used for reading time series data from a text file and writing the data into the Battery Stack Emulator. The emulation will always start from 1 second for initialization. Specific BMS registers can be read from the BMS after inputting the data.



The Battery Stack Emulator does not emulate the exact data acquisition of the Nuvation Energy BMS. Any artifacts attributed to acquisition need to be included with the input data.

While executing the emulation, an operator can access and view the BMS OI in their browser to observe the emulation in progress. The following sections will describe the different files in the folder and how to use the playback function. Before using the playback library, emulation should be stopped using the stop command as defined in <u>Section 4.3.1</u>, "CLI Commands".



Currently, the time resolution on the Battery Stack Emulator is limited to integer seconds.

### 4.5.2.1. Battery Input Data

The battery input data is in the form of a CSV file that contains time series data for the battery measurements. Each row in the CSV file represents a discrete point in time. All columns are described in the table below. The columns have the same syntax as the registers in the BMS. The following table (<u>Table 4</u>, <u>"Columns of the battery input data file"</u>) describes the required columns of the battery input data file in greater detail.

Measurement	Column name	Units	Description
Time	sc_clock[0].seconds	S	The elapsed time when the battery measurements were recorded, starting from zero.

#### Table 4. Columns of the battery input data file

Measurement	Column name	Units	Description
Current	stack_power[0].current	А	The applied current to the stack.
Voltage	cell[n].voltage	V	The measured voltage of cell 'n' in the stack, with multiple columns allowed, one for each cell index.
Temperature	therm[m].temperature	°C	The measured temperature of thermistor 'm' in the stack, with multiple columns allowed, one per thermistor index.
Capacity	stack_soc[0].measured_capacity	Ah	The measured capacity of the battery stack which is only required for the first time period, not every time step.
Voltage	stack_cell_stat[0].min	V	The minimum voltage of a single cell in the stack.
Voltage	stack_cell_stat[0].max	V	The maximum voltage of a single cell in the stack.
Temperature	stack_therm_stat[0].min	°C	The minimum temperature in the stack.
Temperature	stack_therm_stat[0].max	°C	The maximum temperature in the stack.

In the folder sim\_data of the Battery Stack Emulator package, there will be an initial CSV file called battery\_input\_data.csv. The data provided in this file contains sample measurements that can be used to better understand what the input into the Battery Stack Emulator should be. The file should be updated with your unique battery measurement data, keeping in mind the format of the input file.

### 4.5.2.2. BMS Output Registers

The BMS output register file contains the list of registers that are to be read from the Battery Stack Emulator. Each row contains the name of a specific register that is to be read. It should be noted that for components with multiple instances, different register expressions can be used to read multiple values simultaneously. More information of the BMS register syntax can be found in the stack-level *Product Manual*. Similar to the battery input data, the BMS output register file initially found in the emulator package contains a few default registers. The file can be updated with the specific registers that you would like to read from the BMS at the end of every emulated clock cycle.

### 4.5.2.3. Playback Object

The playback object can be built in python by calling the build build\_playback() function. The function has four arguments:

- input\_data\_file: The path to the battery input data, as type string.
- output\_reg\_file: The path to the output register, as type string.
- ini\_soc: The initial state-of-charge of the battery at the beginning of the test, as type int.
- ip: The IP address of the emulator, as defined in <u>Section 4.8, "TCP Ports and Services"</u>.
- port: The emulation API HTTP port of the emulated BMS in the Battery Stack Emulator, as defined in <u>Section 4.8, "TCP Ports and Services"</u>.

After the playback object has been built, there are two methods and one attribute that can be

accessed to run the playback script.

step(): At each emulation clock cycle, the step function can be called to input the latest measurement data into the Battery Stack Emulator.

get\_bms\_output(): After the clock update, the get\_bms\_output() function can be called to read the list of BMS registers defined in the bms output register file. The output data is in the form of a python key/value map where the key is the BMS register name.

finished: A boolean value indicating whether all the data in the CSV file has been inputted into the Battery Stack Emulator and the emulation has finished.

### 4.5.2.4. Run Playback

The emulator package will contain a demo python file called run\_playback.py, that can be used as an example of how the playback function works. The run\_playback.py python file can be run using the following command (in Windows WSL, Linux, or OS X shell):

python3 run\_playback.py --ip 10.202.11.106 --port 53000 input\_file.csv bms\_out\_regs.csv

The function will take the measurement data from the input data file, read the registers listed in the Battery Management System output register file, output the specified output register as a CSV format by default.

The run\_playback.py script supports the following arguments:

Argument	Description	Default Value
in_file	The name of the input playback trace file	N/A (Required)
bms_out_regs	The name of the csv file with bms registers names for output	N/A (Required)
ip	The IP address of the Battery Stack Emulator	localhost
port PORT	The port of the Battery Stack Emulator instance HTTP interface	53000
ini_soc INI_SOC	The initial SOC of the battery stack	100
out_file OUT_FILE	The name of the output playback trace file	playback_trace.csv
delimiter DELIMITER	The delimiter of the playback trace file	1

#### Table 5. Command Line Arguments for run\_playback.py

The run\_playback.py script supports a single emulated BMS playback at the specific port (see <u>Table 8</u>, <u>"Battery Stack Emulator TCP Ports and Services for Stack 'n'"</u> for emulation API ports on emulated BMSs other than the first). To run playback on multiple stacks, multiple script instances must be run together in parallel.

## 4.6. Using the Battery Stack Emulator Modbus TCP Port

To connect to the first instance (i.e. the first stack) of the Battery Stack Emulator Modbus TCP, connect to port 33000 at your nController's IP address. The Modbus TCP writes/reads can be used to set/get Battery Stack Emulator values. See <u>Table 8</u>, "<u>Battery Stack Emulator TCP Ports and Services</u> for Stack 'n'" for connecting to the Modbus TCP server on the other emulated BMS instances.

## 4.6.1. Modbus TCP Addresses

The Battery Stack Emulator Modbus TCP can be used to set voltages, temperatures, and current. Below is a table summary of implemented Modbus addresses:

Direction	Name	Modbus Base Address	Length	Data Size	Units	Notes
Input	Cell Voltage	0	800	16 bits	mV	800 points matched to the real Cell Interface and cell wiring layout
Input	Thermistor Voltage	800	400	16 bits	mV	400 points matched to the real Cell Interface and thermistor wiring layout, expressed as thermistor voltage
Input	Stack Current	1200	2	32 bits	mA	Stack current input. Word order is little-endian
Input	Stack Voltage	1202	2	32 bits	mV	Stack voltage input. Set to 0 to use cell voltages instead. Word order is little-endian
Input	Padding/Reserved	1204	395	16 bits	N/A	
Input	Latch Trigger	1599	1	16 bits	N/A	Transfers holding register inputs to simulator and populates holding register outputs
Input	Padding/Reserved	1600	800	16 bits	N/A	
Output	Contactor Coil Outputs	2400	1	16 bits	Bitfield	Contactor coil status bits (3 LSbs), matched to contactor wiring harness. Read only

#### Table 6. Battery Stack Emulator Modbus TCP Addresses

## 4.7. Using the Platform Interface

## 4.7.1. Launch Platform Interface

The Platform Interface accessible by navigating to <u>http://ncontroller-<serial number>.local/platform</u> and enables configuration and management of the Nuvation Energy Battery Stack Emulator.

This URL can be accessed via a <u>compatible computer</u>.

Replace <serial number> with the Battery Stack Emulator serial number - this can be found on a label on the exterior of the product. Below is an example of a product label, with the relevant serial number listed beside the field "SN".





Made in Canada

Figure 31. Sample product label



The above product label is an example, and the actual label will be different.



The Platform Interface currently supports the most recent versions of Mozilla Firefox and Google Chrome. Other browsers such as Internet Explorer are not supported.

Five main pages can be accessed by using the menu on the left side of the page:

- Functions
- Networks
- Backups
- Settings
- Logs

## 4.7.2. Functions

The Functions page is responsible for installing and upgrading application software.

It is highly recommended to only install/upgrade software under guidance from Nuvation Energy. Incorrectly installing/upgrading software could render the Battery Stack Emulator inoperable.

NUVATION	ENERGY	Unit Management		
$oldsymbol{\mathcal{C}}$ Functions	Install			
🔒 Networks	_	Choose a file to upload.		
🖨 Backups		Choose File Install		
Settings				
<b>i≡</b> Logs	Functions			
		Installed Functions		
	Name	Version	Туре	Status
	cloud_logger	12.2.0	Standalone	Running
	ndisplay	24.2.0	Standalone	Stopped
	msc_application	5.2.0	Standalone	Stopped
	msc_ui	2.2.0	Standalone	Stopped
	msc_bundle	21.2.0	Bundle	Running
	system_monitor	24.2.0	Standalone	Stopped
	dashboard_framework	8.3.1-nuv24.2.0	Standalone	Stopped
	remote_access	10.2.0	Standalone	Running

Figure 32. Nuvation Energy Platform Interface Function

The Functions card displays a list of all functions currently installed along with their respective versions.



It is normal for functions of type Standalone to display the Stopped status if one or more functions of type Bundle are present.

## 4.7.2.1. Installing a Function

- 1. Use the Choose File button to select a file with the extension .fn, .fns, or .fnz.
- 2. Click Install to install the function.

### 4.7.2.2. Upgrading a Function

1. Software may be upgraded in place by installing a newer version without uninstalling the older version.

## 4.7.3. Networks

The networks page shows the current network status of the Battery Stack Emulator and allows for configuration of the network interfaces.

External Networks       Bridge         Backups       IP Address:       10.202.11.126         Settings       Netmask:       255.255.224.0         Image: Settings       Image: Settings       Netmask:         DNS:       10.202.10.0       DHCP:	192.168.123.1
External Networks     Bridge       Backups     IP Address:     10.202.11.126       Settings     Netmask:     255.255.224.0       Logs     DNS:     10.202.10.0	192.168.123.1
External Network         Bridge           IP Address:         10.202.11.126         IP Address:           Netmask:         255.255.224.0         Netmask:           Logs         DNS:         10.202.10.0	192.168.123.1
IP Address:         10.202.11.126         IP Address:           Settings         Netmask:         255.255.224.0         Netmask:           Logs         DNS:         10.202.10.0         DHCP:	192.168.123.1
Itings         Netmask:         255.255.224.0         Netmask:           gs         DNS:         10.202.10.0         DHCP:	
gs DNS: 10.202.10.0 DHCP:	255.255.255.0
	🔿 On 🛞 Off
Gateway: 10.202.0.1	0.85
DHCP: On Off	U Yes I No
STP:	) On 🔿 Off
Required:  Ves  No MAC Address:	3c:ec:ef:58:bc:49
STP: O On  Off	
MAC Address: 3c:ec:ef:58:bc:48	

Figure 33. Nuvation Energy Platform Interface Networks

### 4.7.3.1. Networking

There are two configuration cards on this page:

- External Network: Controls the External Ethernet network on the Battery Stack Emulator
- Bridge: Controls the Internal Ethernet network on the Battery Stack Emulator

Each card shows the following information:

- IP Address: The current IP of the Battery Stack Emulator on that network. Displays Unknown if no address is assigned
- Netmask: The current netmask of the connected network. Displays Unknown if no address is assigned
- DHCP: Whether DHCP will be used to acquire an address. Displays On for yes, and Off for no.
- Required: Whether the network interface is required to be up for proper operation. The Battery Stack Emulator will wait for up to 2 minutes during power-up for interfaces marked 'required' to come up before continuing with system startup
- STP: Spanning Tree Protocol. STP protects inadvertent loops within the network between grouped ports of the Battery Stack Emulator. When enabled, a delay of 30 seconds occurs between a network interface gaining carrier and beginning to forward traffic.
- MAC Address: The MAC address of the Battery Stack Emulator on the network. This address is not modifiable
- *Arrow in the header*: A green up-arrow indicates the network interface has a carrier. A red down-arrow indicates no carrier

If DHCP is disabled on the External Network, the following options will become available:

- DNS: The nameserver address to use for hostname lookups. If no DNS is available, set to 0.0.0.0 to disable
- Gateway: The gateway address to access the Internet from this network. If no gateway is available, set to 0.0.0.0 to disable



To communicate with the Battery Stack Emulator while the gateway is set to 0.0.0.0, the Battery Stack Emulator must be on the same subnet as the gateway.

Clicking the Edit Configuration button switches from showing the current status to showing the configured values. Values can be edited in the fields directly. The field will change from green to red if an invalid value is entered. Click Apply to apply and save the configuration.



The Platform Interface only supports configuring IPv4 networks. Operation of the Battery Stack Emulator on IPv6-only networks is not supported.



The DNS server will receive queries for Internet addresses (for example NTP server addresses), so the DNS server should forward queries to root nameservers for proper operation.



If 2 or more networks overlap with each other, the message "Error: Conflicting Networks" will appear. This may cause undesirable operation.



When applying External network settings involving DHCP, the old IP address will not be released, and this may be reflected by the status IP address not matching the configured value. This ensures that the device will always be reachable. A reboot of the device will release the old address.

### 4.7.3.2. Configuration

For the External network settings, the IP address and other corresponding information are automatically assigned by the DHCP server. For the Internal network settings, it is recommended to keep the default parameters which are listed as follows:

- IP Address: 192.168.1.10
- Netmask: 255.255.255.0

## 4.7.4. Backups

The Backups page is responsible for creating and restoring a state for the Battery Stack Emulator. That state includes configured settings, installed functions, and all logged data at the time of the backup creation.

NUVATION@ENERGY			Unit M	anagement			
C Functions	Creat	e					
暴 Networks		Create a b	packup		Choose a	backup file to upload.	
🚔 Backups		Crea	ite		Choose	File Upload	
Settings							
i≡ Logs	Back	aps					
	Name	Date -	Size	Rename	Download	Restore	Delete
			0.00 GiB	(Available Space 10	00.00 GiB)		

Figure 34. Nuvation Energy Platform Interface Backups

### 4.7.4.1. Create a System Backup

To create a backup of the current state of the system, click on Create. After a few minutes, a new backup file will be displayed under Backups with a name, creation date and size. To rename the file, click on Rename and input the name when prompted.

Date 🔻	Size	Rename	Download	Restore	Delete
2023-06-26, 3:05:22 p.m.	3.22 GiB	Rename	Download	Restore	Delete
	3.22 GiB	(Available Space	96.78 GiB)		
kups/nplatform2-322370	00001-ba	ckup-1687806269.	.nbk at 2023-06-26,	3:10:43 p.m.	
	Date ▼ 2023-06-26, 3:05:22 p.m.	Date →         Size           2023-06-26, 3:05:22 p.m.         3.22 GiB           3.22 giB         3.22 giB	Date ~SizeRename2023-06-26, 3:05:22 p.m.3.22 GiBRename2023-06-26, 3:05:22 p.m.3.22 GiBRename2023-06-26, 3:05:22 GiB3.22 GiBRename	DateSizeRenameDownload2023-06-26, 3:05:22 p.m.3.22 GiBRenameDownload2023-06-26, 3:05:22 p.m.3.22 GiBRenameDownload2023-06-26, 3:05:22 giB3.22 GiBRenameDownload	Date -SizeRenameDownloadRestore2023-06-26, 3:05:22 p.m.3.22 GiBRenameDownloadRestore3.22 GiB(Available Space 96.78 GiB) GiB

#### Figure 35. Nuvation Energy Platform Interface Backup file

A copy of the backup file can be downloaded on a <u>compatible computer</u> by clicking the Download button. At any time, a backup file can be deleted by clicking the Delete button.

### 4.7.4.2. Upload a Backup File

To upload an existing backup file, click on Choose file and select a .nbk file, then click the Upload button.



These files are relatively large and might take time to upload and download to the system.

### 4.7.4.3. Backup Restore

To restore the Battery Stack Emulator to a previous state, click the Restore button that corresponds to the .nbk file with the desired state.



Restoring will delete all current data on the device. Other backups will not be deleted.



If restoring a backup that contains different network settings, you may have to navigate your browser to the new address if this does not happen automatically.

## 4.7.5. Settings

The settings page is responsible for the following:

- Upgrading the Battery Stack Emulator
- Factory Resetting the Battery Stack Emulator
- Rebooting and Powering off the Battery Stack Emulator
- Setting Date, Time, and Timezone
- Importing and Exporting System Configuration Files

NUVATION	ENERGY	Unit Managem	ent	
C Functions	Upgrade		Factory Res	et
Setworks	Platform Version	2.2.6-1708630561	Warning: This action is not re same state as it wa	versible and will reset the unit to the s shipped from the factory.
Backups	Service Pack Version	2.2.0SP-1687379088	Fact	orv Reset
Settings	Platform Channel	stable		
i≡ Logs	Product ID	NUVMSC3-36S-C	Power	
	Serial Number	32204000024	Reboot	Power off
	Platform Result	RESULT_BACKUP_RESTORED		
	Choose	a file to upload.	Date & Time	1
	Choose File	Upgrade	Time 🕜	Timezone 🕜
	_		18/04/2024, 21:48	Etc/UTC
	Configuratio	on		
	Choose	a file to import.		
	Choose File	Import Export		

Figure 36. Nuvation Energy Platform Interface Settings



The above screenshot of the settings page is an example, the actual page will be different.

### 4.7.5.1. Upgrading the Battery Stack Emulator



It is strongly recommended to only upgrade software under guidance from Nuvation Energy. Incorrectly upgrading software could render the Battery Stack Emulator inoperable.

To upgrade the Battery Stack Emulator, click the Choose File button to select a file with an extension of .nup or .nosp. Then, click Upgrade to upgrade the unit.



6

It is always recommended to create a backup before upgrading.



The upgrade process may take a couple minutes, so please wait for the upgrade process to complete. The page will automatically refresh once the upgrade is complete.



Downgrading the Battery Stack Emulator is not an accessible feature. To revert to a previous version, please use the backup/restore feature. Please contact <u>support@nuvationenergy.com</u> for assistance with downgrading.

### 4.7.5.2. Factory Reset the System



It is strongly recommended to only factory reset the unit under guidance from Nuvation Energy. This action is not reversible and will reset the unit to the same state as it was shipped from the factory.

To reset the Battery Stack Emulator, click the Factory Reset button.



The reset process may take a few minutes, so please wait for it to complete. The page will automatically refresh once the reset is complete. However, the process will reset all network settings, so the Battery Stack Emulator may no longer be reachable without adjusting the computer's network settings.

### 4.7.5.3. Rebooting the System

To reboot the Battery Stack Emulator, click on the Reboot button and wait until the unit has been rebooted.



The Platform Interface will not be functional while the Battery Stack Emulator is rebooting.

### 4.7.5.4. Powering off the System

To power off the Battery Stack Emulator, click on the Power off button. Alternatively, pressing the physical power button on the unit will have the same effect. Following a shutdown, the physical power button can be pressed to restart the unit.



Before removing power from the Battery Stack Emulator, ensure that the unit has been powered off either through the Platform Interface or the physical power button. Abruptly removing power while the unit is still on may lead to internal file corruption or damage causing the unit to become inoperable.

### 4.7.5.5. Setting the Date, Time, and Timezone

The Timezone and Date/Time are individually configurable.

#### Setting the Date and Time

- 1. Click the blue edit-button to the right of the Time label.
- 2. Select the date and time by clicking on the field that is shown.
- 3. Click Apply to save the changes or Cancel to discard the changes.

#### Setting the Timezone

- 1. Click on the blue edit-button to the right of the Timezone label
- 2. Select the desired timezone from the dropdown list.
- 3. Click Apply to save the changes or Cancel to discard the changes.

### 4.7.5.6. Configuration Import and Export

Configuration files are YAML files that contain settings to be uploaded to the system.



Please contact <a href="mailto:support@nuvationenergy.com">support@nuvationenergy.com</a> for more information on configuration files.

To upload a configuration file:

- 1. Click the Choose File button.
- 2. Select a YAML configuration file.
- 3. Click the Import button. A notification box will appear indicating the configuration was uploaded.



To get the configuration file currently uploaded on the system. Click the Export button.

# NUVATION® ENERGY

## 4.7.6. Logs

The logs page allows debugging information to be downloaded from the Battery Stack Emulator. These logs can allow Nuvation Energy to more easily assist with support.

NUVATION@ENERGY		Unit Manageme	ent
C Functions	Logs		
🚓 Networks			
🖨 Backups	Priority	•	Search
Settings	Since		Until
i≣ Logs		Dow	rnload

Figure 37. Nuvation Energy Platform Interface Logs

### 4.7.6.1. Downloading Logs

Set the Priority, Search, Since, and Until options as requested by Nuvation Energy support and click Download. Save the resulting .logx file to your computer so it can be relayed to Nuvation Energy support.

## 4.8. TCP Ports and Services

By default, the following port mapping is used for HTTP and Modbus TCP access for the first instance of an emulated BMS:

Port	Service Name	Protocol	Description
8000	BMS HTTP	НТТР	The emulated BMS HTTP interface of the emulated Battery Management System which can be used to connect with the OI.
503	BMS Modbus	Modbus TCP	The emulated BMS Modbus interface for accessing the SunSpec Energy Storage Models.
53000	Emulation API	HTTP	The interface to be used for configuration upload and playback script execution.
33000	Emulation Modbus	Modbus TCP	The interface to be used for setting Battery Stack Emulator values over Modbus.
50022	Emulation CLI	SSH	The interface for CLI emulator access. Username and password will be provided by Nuvation Energy.

#### Table 7. Battery Stack Emulator TCP Ports and Services for Stack '0'

The Battery Stack Emulator has up to 16 instances of emulated stacks, with the port number incremented for each subsequent stack. The table below shows the ports for stack 'n', where the first stack has 'n = 0', the second stack as 'n = 1' etc.

#### Table 8. Battery Stack Emulator TCP Ports and Services for Stack 'n'

Port	Service Name
8000 + n	BMS HTTP

Nuvation Energy Battery Stack Emulator - Product Manual

Port	Service Name
503 + n	BMS Modbus
53000 + n	Emulation API
33000 + n	Emulation Modbus
50022 + n	Emulation CLI

For example, the fourth instance with index 'n = 3' will have port 8003 for BMS HTTP, 53003 for emulator HTTP, port 506 for Modbus TCP, port 33003 for emulator Modbus, and port 50025 for SSH.

In some cases, the SSH client may emit error messages similar to the following immediately at startup:

channel 5: open failed: connect failed: Connection refused

This is usually the result of having the Operator Interface or some other program actively trying to connect to the emulator before it is running.

# 5. Appendix A: Operating Limits



i

NUVATION<sup>®</sup>

**ENERGY** 

Exceeding the maximum ratings will damage the module.

## 5.1. Electrical Characteristics

Symbol	Parameter	Conditions	Min	Тур	Max	Units
		Power Specifications				
	Input Voltage	-	100	-	240	V AC
	Input Frequency	-	50	-	60	Hz
+ V <sub>in</sub>	Input Current	$V_{in} = 120 \text{ V AC}$	-	-	5	A AC
	Input Current	$V_{in} = 240 \text{ V AC}$	-	-	2.5	A AC
		Ethernet Specifications				
RJ45 Port 1-9	Connection Speed	10BASE-T 100BASE-TX 1000BASE-T	10	-	1000	Mb/s
	Twisted-pair cable rating	-	Cat 5e	-	Cat 6	
	Ethernet jack rating	-	-	Cat6	-	
RJ45 Port 10-11	Connection Speed	1GBASE-T 10GBASE-T	1	-	10	Gb/s
	Twisted-paid cable rating	-	Cat 6	-	-	
	Ethernet jack rating	-	-	Cat6	-	
SFP+ Port 12-13	SFP+ Port Speed	-	1	-	10	Gb/s

Systems involving more than 10 Ethernet connected ports for equipment will require an external network Ethernet switch to be connected to the nController EMS.

This external switch is not provided. An industrial grade, un-managed switch is recommended.

## 5.2. Environmental Conditions

Symbol	Parameter	Conditions	Min	Max	Units
	Thermal	Specifications			
т	Operating Temperature	-	5	45	°C
l <sub>a</sub>	Storage Temperature	-	-40	70	°C
	Humidity	Specifications			
RH	Operational Relative Humidity	Non-Condensing	8	90	%
	Storage Relative Humidity	Non-Condensing	5	95	%



If the Battery Stack Emulator is stored at temperatures below 5 °C, it must be warmed up in a 20 °C or warmer environment for 45 minutes before applying power.

Powering the unit below 5  $^{\rm o}{\rm C}$  may impact data logging or cause other unexpected behaviour.



The Battery Stack Emulator unit should not be shipped while installed in a rack.

## 5.3. Regulatory Compliance

Standard	Name	
	Electromagnetic Emissions	
FCC Class B	US Federal electromagnetic radiation limits	
EN 55032 Class B	European Electromagnetic compliance testing of multimedia equipment	
EN 61000-3-2/3-3	European Electromagnetic limits for harmonic current emissions	
CISPR 32 Class B	International Electromagnetic compatibility of multimedia equipment	
Electromagnetic Immunity		
EN 55024/CISPR 24	European information technology equipment immunity characteristics	
Safety		
CSA/EN/IEC/UL 60950-1 Compliant	Information technology equipment safety general requirements	
CE Marking	Compliant with European Union (EU) directives and regulations	

# 6. Appendix B: List of Supported Equipment

## 6.1. Supported UPS Devices

The following UPS devices have been tested and are supported with Nuvation Energy products:

- APC SRT3000RMXLA
- APC BR1000MS
- CPS CP1500PFCLCD
- CPS CP1350PFCLCD



Nuvation Energy guarantees product compatability with the above family models.

Excluding the UPS devices mentioned above, following family models are likely to be compatible, however have not been thoroughly tested by Nuvation Energy:

- APC Smart-UPS family models
- Other APC Back-UPS family models
- CPS CP\*PFCLCD family models
- CPS OR\*PFCRT\* family models
- CPS BRG\*AVRLCD family models
- CPS CP\*AVRLCD family models
- CPS CP\*AVR\* family models



Nuvation Energy **does not** guarantee product compatability with the above family models.



The Battery Stack Emulator can communicate with UPSes via USB and Ethernet.